

MOUNTING BASE REMOVAL INSTRUCTIONS

Step 1: Use a heat gun.

Step 2: Set heat gun to low temperature or between 400 – 500 degrees F.

Step 3: Aim heat gun 3 inches away from the mounting base.

Step 4: Heat for about 3-5 minutes.

Step 5: Use the mounting arm of the mirror as an anchor and gently pull the arm down towards you to remove the mounting base.

Step 6: If mounting base does not remove, heat for an additional minute or two and try again.

Step 7: Use a razor blade to carefully scrape off any glue residue left on the windshield.

Step 8: Let cool and then wipe area clean with a damp cloth.